

User Guide

Danfoss *Icon*™ Display

Room Thermostat, 230 V

Introduction


Danfoss *Icon*™ Display is a room thermostat especially designed for floor heating systems. It comes in four different designs to suit markets worldwide.

Danfoss *Icon*™ Display is very intuitive and easy to use. Just set your desired comfort temperature, and the thermostat will control the room temperature in accordance with your setting.


Wake up the thermostat

Touch the screen to wake up **Danfoss *Icon*™ Display**.

The actual room temperature is displayed. The **Heating** icon  is displayed, if the thermostat has turned on the heat.



Touch  to return to the previous screen.

The screen turns off after 10 seconds without any action.



Set the temperature

Wake up the thermostat



Touch  or  to set the desired room temperature.

The temperature flashes to indicate setting is in progress.


Confirm your setting by touching .



Reset to default factory settings


Press  and  simultaneously for at least 3 seconds to reset **Danfoss *Icon*™ Display** to the default factory settings.



The display toggles between **dE L** and **AL L**.

Confirm by touching .

Menus


Wake up the thermostat.

Press  for 3 seconds to open the User menus **ME. 1** and **ME.2**.



Toggle the menus with  or .



Choose menu with .


(To open the Installer menus **ME.3** and **ME.4**, press  again for 3 seconds).



ME. 1 Temperature limitation

SE t and **HI** toggles with the temperature on the screen. Set highest temperature with  or .

SE t and **LO** toggles with the temperature on the screen. Set lowest temperature with  or .

Confirm your choice with .

Default temperature range: 5 to 35° C.


ME.2 Product ID

Production code.

Menu 3 and 4 are only relevant for the installer


ME.3 Set actuator type

Choose between Normally Closed **NC** or Normally Open **NO** with  or .

Confirm with .

ME.4 Set heat emission characteristics of the floor

Choose Fast **FA S**, Medium **ME d** or Slow **SL O** heat emission characteristics with  or .

Confirm with .

Danfoss A/S

Floor Heating Hydronics • Ulvehavevej 61 • DK-7100 Vejle • Denmark • Phone: +45 7488 8500 • Fax: +45 7488 8501
heating@danfoss.com • www.floorheating.danfoss.com

Danfoss can accept no responsibility for possible errors in catalogues, brochures and other printed material. Danfoss reserves the right to alter its products without notice. This also applies to products already on order provided that such alterations can be made without subsequent changes being necessary in specifications already agreed.
All trademarks in this material are property of the respective companies. Danfoss and the Danfoss logotype are trademarks of Danfoss A/S. All rights reserved.